

This document provides additional assistance with wiring your Extron IP Link enabled product to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific Extron IP Link enabled product or the controlled device manufacturer supplied documentation.

---

***Device Specifications:***

Device Type: Matrix Switcher  
Manufacturer: Atlona  
Firmware Version: N/A  
Model(s): AT-HD-V16x2

***Version History:***

Driver Version	Date	IP Link Compiler	GC Version	Notes
1	1/31/2013	1.5.1	3.3.2	Initial version.

***Driver Notes:***

**IP Link® Device Interface  
Communication Sheet****Control Commands & States:**

<b>Executive Mode</b>	On Off
<b>Output 1 to 2</b>	1 to 16
<b>Power Control</b>	On Off
<b>Preset Clear</b>	0 to 9
<b>Preset Recall</b>	0 to 9
<b>Preset Save</b>	0 to 9
<b>Reset</b>	Execute

**Status Available:**


<b>Connection Status</b>	Connected Disconnected
<b>Output 1 to 2</b>	1 to 16

**MLC60 Series Supported Commands:**

<b>Executive Mode</b>	On Off
<b>Output 1 to 2</b>	1 to 16
<b>Power Control</b>	On Off
<b>Preset Clear</b>	0 to 9
<b>Preset Recall</b>	0 to 9
<b>Preset Save</b>	0 to 9
<b>Reset</b>	Execute

**Cable and Adapter Requirements:**

F/F RS232 Straight Serial Cable

**Notes for the Device:****Serial communication:****Port Type:** RS-232**Baud Rate:** 9600**Data Bits:** 8**Parity:** None**Stop Bits:** 1**Flow Control:** None**Pin Assignments Diagram:**

Note: Captive screw connector may also be used as a serial connection.

**General Notes:**